



Local: 863-614-1900 ★ Toll Free: 866-770-4930 ★ Fax: 888-782-3072
E-mail: telephoneman@telephonemanofamerica.com or Skype Us

TelephonemanOfAmerica.com or shop.telephonemanofamerica.com

TELEPHONE MAN OF AMERICA
Earning Your Business Every Step of the Way!

Specializing in Telecom Equipment of all Brands, Carrier Services, Technician Services, Maintenance Agreements and Purchasing Excess Telecom Equipment!

I will always do my best to match or beat any competitors bid!

Part No. P0919430 02

CallPilot

**Message Networking
User Guide**

NORTEL
NETWORKS™

CallPilot Message Networking User Guide

Copyright © 2001 Nortel Networks

All rights reserved. 2001.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

Trademarks

NORTEL NETWORKS is a trademark of Nortel Networks.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

CallPilot Message Networking User Guide

About Message Networking

This guide explains how to use Message Networking with your personal mailbox. Message Networking links CallPilot or other voicemail systems at different locations.

Digital networking and AMIS

Message Networking uses digital networking and Audio Message Interchange Specification (AMIS) to exchange messages.

Digital networking

Digital networking uses Transmission Control Protocol/Internet Protocol (TCP/IP) to enable the exchange of voice and Fax messages between users at different sites on a network.



Note: Any voice message that you use send over the Internet using digital networking can be subject to interception by unauthorized parties.

AMIS

AMIS provides voice messaging to mailboxes at different sites on a communication network. A network is a collection of offices, locations or sites connected by telecommunication links. Each site on the network must have AMIS to send, receive and reply to network messages.

How Message Networking works





Sending a message across a network is as easy as sending a message down the hall. There are three ways to send a network message.

You can use:


- a Network Delivery Mailbox
- Site-Based Addressing
- Direct Addressing (available for AMIS only)



Note: Network messages can be composed and sent only from your mailbox.

You cannot send a network message by using the Leave Message feature (   ).

Sending a network message



The diagram [Sending a network message](#) shows how messages are sent between different company sites on the same network. In the example, Sue works in the Vancouver office and Mark works in the Miami office.

If Sue wants to send Mark a message, she can send the message using Site-Based Addressing, Direct Addressing, or to Mark's Network Delivery Mailbox. Since Mark has a Network Delivery Mailbox on the local Vancouver system, it is convenient for Sue to send the message to Mark's Network Delivery Mailbox.

Although Mark's Network Delivery Mailbox appears on the Vancouver system the message is automatically delivered to his mailbox in Miami. The network delivery information, such as the site prefix for the Miami site and Mark's mailbox number (4546) in Miami, is added to the Network Delivery Mailbox when you create it.

Sending a message to a Network Delivery Mailbox is as easy as sending a message to anyone at your site.

If Mark wants to send Sue a message, he must use Site-Based Addressing. Sue does not have a Network Delivery Mailbox on the Miami system.

Before Mark can send the message he needs to know the site prefix of the Vancouver site and Sue's mailbox number in Vancouver. The System Administrator can give Mark the Vancouver site prefix. After Mark records the message and enters the network delivery information, the network message is automatically delivered to Sue's mailbox.

What you need to know to use Message Networking

You must know how to use CallPilot to send messages to mailboxes at other sites. This includes knowing how to open your mailbox, record messages, send messages and retrieve messages. For information about using CallPilot features, refer to the *CallPilot Quick Reference Guide* for the interface you use, or the *CallPilot Reference Guide*.

To use this guide, you must determine which phone interface you use, and follow the procedures for that interface. For information about determining which interface you use, refer to [“Checking which mailbox interface you use”](#) on page 6.

Checking which mailbox interface you use

CallPilot supports the Norstar Voice Mail and CallPilot interfaces.

Use this procedure to check which mailbox interface you use, then follow the procedures that apply to your interface.

To check which mailbox interface you use

- 1 Press **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Check the display to see which interface you use:

```
0 new 0 saved  
PLAY REC ADMIN
```

This is the Norstar Voice Mail interface.

```
No messages  
COMP MBOX EXIT
```

This is the CallPilot interface.

- 3 Press **[END]** to end the session.

Sending a message using a Network Delivery Mailbox

Network Delivery Mailboxes make it easy to send messages to a mailbox at a remote location. The Network Delivery Mailbox makes sending a message across the country as easy as sending it down the hall. A Network Delivery Mailbox is a pre-programmed direct address to a mailbox at a different site on the network. Each Network Delivery Mailbox has a local mailbox number. The destination site user's name appears in the company directory.

To send a message using a Network Delivery Mailbox, you need the Network Delivery Mailbox number. Ask your System Administrator to give you a list of Network Delivery Mailboxes or create a Network Delivery Mailbox for you.

The messages you record must be longer than three seconds. The system times out after five seconds of silence.

To send a message using a Network Delivery Mailbox- Norstar Voice Mail

- 1 Open your mailbox using **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Enter your mailbox password and press **OK** or **#**.
- 3 Press **REC** or **3**.
- 4 At the tone record your message.
- 5 Press **OK** or **#** to end the recording.
- 6 Press **OK** or **#** to accept the recording.
- 7 Enter the Network Delivery Mailbox number.
- 8 Press **SEND** to send the message
or
press **OPTS** to assign message Delivery Options Certified, Urgent
or Timed Delivery
or
press **CC** to send the message to another recipient.
- 9 Press **[*]** to end the session.

```
Pswd:
OTHR  RETRY  OK
```

```
0 new  4 saved
PLAY  REC  ADMIN
```

```
Record message:
```

```
Record message:
RETRY  PAUSE  OK
```

```
Accept rec?
RETRY  PLAY  OK
```
















```
Mbox:
DIR          QUIT
```

```
Miami,sales
OPTS  CC  SEND
```

```
Will deliver
```

```
0 new  0 saved
PLAY  REC  ADMIN
```

To send a message using a Network Delivery Mailbox - CallPilot

- 1 Open your mailbox using  9 8 1.
Follow the voice prompts or the display button options to open your mailbox.

- 2 Press COMP or   to open the Compose Message menu.

- 3 Enter the Network Delivery Mailbox number and press DONE or .
- 4 Press REC or  to begin recording.

- 5 Press OK or  when you are done.

- 6 Press SEND or   to send the message.

- 7 Press  to end the session.


Sending a message using Site-Based Addressing

Site-Based Addressing lets you send a message to a mailbox at another location on the network. To use Site-Based Addressing to send a message, you must know the network address of the destination site and the mailbox number of the person you want to send the message to.

Ask your System Administrator for a list of destination sites on your network.

To send a message using Site-Based Addressing - Norstar Voice Mail

- 1 Open your mailbox using .
Follow the voice prompts or the display button options to open your mailbox.
- 0 new 4 saved
PLAY REC ADMIN
- 2 Press REC or .
- Record message:
- 3 At the tone, record your message.
The message you record must be longer than three seconds. The system times out after five seconds of silence.
- Record message:
RETRY PAUSE OK
- 4 Press OK or to end the recording.
- Accept rec?
RETRY PLAY OK
- 5 Press OK or to accept the recording.
- Mbox:
DIR QUIT
- 6 Press .
- Address type?
NETW AMIS
- 7 Press NETW .
- Network:
RETRY OK
- 8 Enter the destination site prefix and mailbox number and press OK or .
- <site name>
OPTS CC SEND
- 9 Press SEND to send the message as it is
or
press OPTS to assign message Delivery Options Certified, Urgent or Timed Delivery
or
press CC to send the message to another recipient.
- Network msg
VIEW SEND
- 10 Press SEND to transmit the message.
- 0 new 0 saved
PLAY REC ADMIN
- 11 Press to end the session.

To send a message using Site-Based Addressing - CallPilot

- 1 Press **☎** **9** **8** **1**.
Follow the voice prompts or display options to open your mailbox.
- 2 Press **COMP** or **7** **5** to open the Compose Message option.
- 3 Enter the site prefix and the mailbox number and press **OK** or **#**.
- 4 The display shows the destination mailbox name and mailbox number.
- 5 You can enter another address or press **DONE** or **#** if you are finished entering addresses.
- 6 Press **REC** or **5** and record your message at the tone. The message you record must be longer than three seconds. The system times out after five seconds of silence.
- 7 Press **OK** or **#** to end your recording or press **REREC** to erase and re-record your message.
- 8 Press **SEND** or **7** **9** to send the message.

To:
NAME SPEC DONE

Site:<xxxx>

Dest mb:<xxxx>

To:
NAME SPEC DONE

EMPTY
REC

Recording....
REREC OK

Rec stopped
PLAY DEL SEND

Sending a message using Direct Addressing

Direct Addressing lets you send a voice message to a mailbox at a different location on a network. To use Direct Addressing you must know the destination site phone number and the mailbox number of the person you want to send a message to. Direct Addressing is available for AMIS only.

Ask your System Administrator for the destination site's phone number and mailbox numbers.

To send a message using Direct Addressing - Norstar Voice Mail

- 1 Press **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Enter your mailbox password and press **OK** or **#**.
- 3 Press **REC** or **[3]**.
- 4 At the tone, record your message.
The message you record must be longer than three seconds. The system times out after five seconds of silence.
- 5 Press **OK** or **#** to end the recording.
- 6 Press **OK** or **#** to accept the recording.
- 7 Press **# #**.
- 8 Press **AMIS**.
- 9 Enter the destination site phone number and press **OK**.
- 10 Enter the destination mailbox number and press **OK**.
- 11 Press **OTHR** to review or send the message
or
press **OPTS** to assign message Certified, Urgent, or Timed Delivery options
or
press **CC** to send the message to another recipient.
- 12 Press **SEND** to transmit the message.
- 13 Press **[*]** to end the session.

```
Pswd:
OTHR  RETRY  OK
```

```
0 new      4 saved
PLAY  REC  ADMIN
```

```
Record message:
```

```
Record message:
RETRY  PAUSE  OK
```

```
Accept rec?
RETRY  PLAY  OK
```

```
Mbox:
DIR          QUIT
```

```
Address type?
NETW        AMIS
```

```
Ph:
RETRY      OK
```

```
Destmb:
RETRY      OK
```

```
AMIS msg
OPTS  CC  OTHR
```

```
Network msg
VIEW  SEND
```

```
0 new  0 saved
PLAY  REC  ADMIN
```

To send a message using Direct Addressing - CallPilot

- 1 Open your mailbox using **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- No messages
COMP MBOX EXIT
- 2 Press **COMP** or **[7] 5** to open the Compose Message menu.
- To:
 NAME **SPEC** CNCL
- 3 Press **SPEC** or **[1] 9**.
- Dest ph:
 RETRY **OK**
- 4 Enter the phone number of the remote site and press **OK** or **#**.
- <xxxxxx>
 ADD **OK**
- 5 Press **OK** or **#** to continue or press **ADD** or **[2]** to add special characters. Press **OK** or **#** when you are done adding special characters.
- Dest mb:
 RETRY **OK**
- 6 Enter the mailbox number at the remote site.
- <xxxx>
 RETRY **OK**
- 7 Press **OK** or **#** to accept the mailbox number.
- To:
 NAME SPEC **DONE**
- 8 Press **DONE** or **#** or enter another address to send the message to.
- Empty
REC
- 9 Press **REC** or **[5]** to record your message. The message you record must be longer than three seconds. The system times out after five seconds of silence.
- Recording...
 REREC **OK**
- 10 Press **OK** or **#** when you are done recording or press **REREC** or **[5]** to rerecord your message.
- Rec stopped
 PLAY DEL **SEND**
- 11 Press **SEND** or **[7] 9** to send the message.
- Msg delivered
- 12 Press **[*]** to end the session.

Replying to network messages

You can reply to a network message using the Reply Feature. You must have the network Reply Feature enabled in order to reply to a message. For more information, ask your System Administrator.

To reply to a network message - Norstar Voice Mail

- 1 Open your mailbox using **6 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 1 new 4 saved
PLAY REC ADMIN
- 2 Press **PLAY** or **2** to play your new messages or
press **6** to listen to your saved messages.
- End of message
REPLY ERASE NEXT
- 3 After you listen to the message, press **REPLY**.
- Reply network msg
MSG QUIT
- 4 Press **MSG**.
- Reply to:
SNDR ALL
- 5 Press **SNDR** to send your reply to the sender or
press **ALL** to send your reply to all the people that received the message.
- Record message:
- 6 Record your reply message.
The message you record must be longer than three seconds. The system times out after five seconds of silence.
- Record message:
RETRY PAUSE OK
- 7 Press **OK** to end your recording.
- Accept rec?
RETRY PLAY OK
- 8 Press **OK** to accept your recording.
If you are using digital networking, the display in step 10 appears. If you are using AMIS, go to step 11.
- Networkmsg
OPTS CC SEND
- 9 Press **SEND** to send the message or
press **OPTS** to assign message Delivery Options Certified, Urgent or Timed Delivery or
press **CC** to send the message to another recipient.
- Will deliver


AMIS msg
OPTS CC OTHR

- 10** Press OTHR to go to the next display and review or send the message as it is
or
press OPTS to assign message Delivery Options Certified, Urgent or Timed Delivery
or
press CC to send the message to another recipient.


Network msg
VIEW SEND



- 11** Press SEND to transmit the message.

End of message
REPLY ERASE NEXT





- 12** Press  to end the session.

To reply to a network message - CallPilot





- 1** Open your mailbox using  9 8 1 .
Follow the voice prompts or the display button options to open your mailbox.

- 2** Press PLAY or  to play your new messages
or
press  to listen to your saved messages.


End message
RESP DEL NEXT

- 3** After you listen to your messages, press RESP or   .
If you press   , go to step 5.


Respond by
REPLY FORW

- 4** Press REPLY or   to reply to a message
or
FORW or   to forward a message.



Empty
REC


- 5** Press REC or  to record a message.
The message you record must be longer than three seconds. The system times out after five seconds of silence.

Recording...
REREC OK

- 6** Press OK or  when you are done recording.

Rec stopped
PLAY DEL SEND

- 7** Press   to send the message.

- 8** Press  to end the session.

Forwarding a Fax Message using Site-Based Addressing



Note: You can send and receive Fax messages only on CallPilot or Business Communications Manager systems that have the Fax option installed. Ask your System Administrator for a list of Fax sites on your network.

If the receiving site cannot receive a Fax message, you receive Non Delivery Notification.

You can forward a Fax message that you received to a Site-Based Address and add an introductory voice message. The combined voice and Fax message appears as a Fax message in the destination mailbox.

You can also forward a received Fax message to a Network Delivery Mailbox. Refer to [“Forwarding a Fax Message to a Network Delivery Mailbox”](#) on page 18.

When you forward a Fax message, a new cover sheet is added to the original Fax message as part of the new message. However, if the Fax message already has a CallPilot generated Fax cover sheet, it is replaced by a new Fax forward cover sheet.

The cover sheet contains:

- the date and time the Fax is created
- the directory name and telephone number of the sender
- the telephone number of the recipient
- the Fax identification (ID) number
- the number of pages to follow

To forward a Fax message using Site-Based Addressing - Norstar Voice Mail

- 1 Open your mailbox using **☎ 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.

```
Pswd:
OTHR  RETRY  OK
```

- 2 Enter your mailbox password and press **OK** or *****.

```
1 new  4 saved
PLAY  REC  ADMIN
```

- 3 Press **PLAY** or **2** to play your new messages
or
press **6** to play to your saved messages
until you find the Fax message that you want to forward.

```
End of message
COPY  ERASE  NEXT
```

- 4 Press **COPY** or **5**.

Copy fax
MBOX OTHR

5 Press MBOX or 1 to forward the Fax message.

Record intro?
YES NO

6 Press YES or 1 to record an introduction to the Fax message or press NO or 2 if you do not want to record an introduction to the forwarded Fax message. and go to step 9.
The message you record must be longer than three seconds. The system times out after five seconds of silence.

Record Message:
RETRY PAUSE OK

7 Press OK to end the recording.

Accept rec?
RETRY PLAY OK

8 Press OK to accept the recording.

9 Press # #.

Address type?
NETW AMIS

10 Press NETW.
This display appears only if AMIS is enabled. If AMIS is not enabled, the display in step 12 appears.

Network
RETRY OK

11 Enter the destination site prefix and the destination mailbox number and press OK.

<site name>
OPTS CC SEND

12 Press SEND to send the message as it is. Press OPTS to assign message Delivery Options Certified, Urgent or Timed Delivery. Press CC to send the message to another recipient.

Network msg
OPTS CC SEND

13 Press SEND to send the message now.

To forward a Fax message using Site-Based Addressing - CallPilot

- 1 Open your mailbox using **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Press **[2]** to play the current message
or
press **[6]** to play the next message, until you locate the Fax message you want to forward.
- 3 Press **[7] [3]** to forward the message.

To:
NAME SPEC CNCL

- 4 Enter the destination site prefix and mailbox number and press **OK** or **[#]**.

Site:<xxxx>

- 5 The display shows the destination site name and mailbox number.

Dest mb:<xxxx>

To:
NAME SPEC **DONE**

- 6 Press **DONE** or **[#]**.

Empty
REC

- 7 Press **REC** or **[5]**.

Recording...
REREC **OK**

- 8 Press **OK** or **[#]**.

Rec stopped
PLAY DEL **SEND**

- 9 Press **SEND** or **[7] [9]**.

Forwarding a Fax Message to a Network Delivery Mailbox



Note: You can send and receive Fax messages only on CallPilot or Business Communications Manager systems that have the Fax option installed. Ask your System Administrator for a list of Fax sites on your network.

If the receiving site cannot receive a Fax message, you receive Non Delivery Notification.

You can forward a Fax message that you received to a digital networking Network Delivery Mailbox and add an introductory voice message that becomes part of the new message. The message appears as a Fax message in the destination mailbox.

You can also forward a received Fax message using Site-Based Addressing. For more information, refer to [“Forwarding a Fax Message using Site-Based Addressing”](#) on page 15.

A forwarded Fax message has a new cover sheet added to the original Fax message. However, if the Fax message already has a CallPilot-generated Fax cover sheet, it is replaced by the new Fax forward cover sheet.

The new cover sheet shows:

- the date and time the Fax was created
- the directory name and telephone number of the sender
- the telephone number of the recipient
- the Fax identification (ID) number
- the number of pages to follow

To forward a Fax message to a Network Delivery Mailbox - Norstar Voice Mail

- 1 Open your mailbox using **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Enter your mailbox password and press **OK** or **[*]**.
- 3 Press **PLAY** or **[2]** to play your new messages or press **NEXT** or **[6]** until you find the Fax message you want to forward.
- 4 Press **COPY** or **[5]**.

```
Pswd:
OTHR  RETRY  OK
```

```
1 new  4 saved
PLAY  REC  ADMIN
```

```
End of message
COPY  ERASE  NEXT
```

```
Copy fax
MBOX      OTHR
```

5 Press MBOX or 1 to forward the Fax message.

```
Record intro?
YES       NO
```

6 Press YES or 1 to record an introduction to the Fax message or press NO or 2 if you do not wish to record an introduction to the forwarded Fax message and go to step 9.

The message you record must be longer than three seconds. The system times out after five seconds of silence.

```
Record intro:
RETRY     OK
```

7 Press OK to end the recording.

```
Acceptrec?
RETRY    PLAY    OK
```

8 Press OK to accept the recording.

```
Mbox:
DIR      QUIT
```

9 Enter the Network Delivery Mailbox number.

```
Miami,sales
OPTS    CC      SEND
```

10 Press SEND to send the message

or

press OPTS to assign message Delivery Options Certified, Urgent or Timed Delivery

or

press CC to send the message to another recipient.

```
Another copy?
YES       QUIT
```

Miami,sales is an example. The Network Delivery Mailbox name appears in the display.

To forward a Fax message to a Network Delivery Mailbox - CallPilot

- 1 Open your mailbox using **[*] 9 8 1**.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Press **[2]** to play the current message
or
press **[6]** to play the next message, until you locate the Fax message you want to forward.
- 3 Press **[7] [3]** to forward the message.

To:
NAME SPEC CNCL

- 4 Enter the Network Delivery Mailbox number.

<xxxx>

- 5 The display shows the mailbox name.

To:
NAME SPEC DONE

- 6 Press DONE or **[#]**.

Empty
REC

- 7 Press REC or **[5]** to record an introductory voice message.
The message you record must be longer than three seconds. The system times out after five seconds of silence.

Recording...
REREC OK

- 8 Press OK or **[#]**.

Rec stopped
PLAY DEL SEND

- 9 Press SEND or **[7] [9]**.